CS 361 Computer Networks Lab

Assignment 8

Samanway Maji Student ID – 202151136 Date – 16/11/2023

Questions:

1. Create a network between 3 pcs, Switch, Router and server.

Components used:










Network Diagram:




The PCs, server and the router are connected to the Fast Ethernet ports of the switch. The green symbol shows connection has been established properly.

2. Take two wireless access points and connect them to the switch.

Components used:



Network Diagram:



The Access Point has been connected to the switch. An access point (AP) is a networking device that allows wireless devices to connect to a wired network using Wi-Fi. Access points play a crucial role in wireless networking by providing a bridge between wired and wireless networks.

3. Connect at least 10 wireless devices (wireless desktop, laptop, printers, wireless mobile, tabs & etc..) to each access point.

Components used:













Network Diagram:



A total of 10 devices has been connected to each of the access point as shown in the diagram. However, before this, the access points need to be configured, for other end points in the network to recognize and connect to it.

SSID and Pass phrases need to be configured for both the Access Points, and changes are to be made in Port1.





As a next step, PCs need to undergo some changes as well, so that they can connect to the wireless network, the first step is to attach a module that will help in allowing wireless connection. This is achieved using the Linksys – WMP300N module.

The Linksys WMP300N is a wireless network adapter designed for desktop computers, enabling them to connect to Wi-Fi networks. Utilizing the 802.11n standard, it offers high-speed wireless connectivity on both 2.4 GHz and 5 GHz bands. The adapter's configuration utility allows users to manage settings such as wireless security and connection profiles,


providing a reliable and flexible solution for adding Wi-Fi capabilities to desktop computers.

The below diagram shows the Linksys WMP300N adapter connected to the PCs, Laptops, and printers. Smartphones don't need manual addition of the same.






Following this, the devices are ready to be connected to the wireless network. Now the SSID of the access point and its respective pass phrase is to be added to the device, to enable connection.



Successful connection is shown by dashed lines from the access points to the device.




4. Connect a wireless server to access point 0 & access point 1.

Components used:




Network Diagram:




The process is roughly the same for the connection of servers to the access point as well, with intitally the Linksys WMP300N network adapter attached to the servers as a module, which enables wireless connection, and then adding the SSID of the access point to which it needs to be connected and its respective pass phrase.





Next the SSID and pass phrase of the access point to which it needs to be connected is added to the server.



Successful connection is shown by dashed lines from the access points to the server.

